

Flexispot Limited Warranty

This limited warranty offered by Flexispot covers defects in material or workmanship in new Flexispot products. This warranty extends to the original purchaser only and is non-transferable. Only consumers purchasing Flexispot products from authorized Flexispot retailers or resellers may benefit from our limited warranty.

What is Covered?

The Flexispot limited warranty covers our products against defects in material or workmanship as follows:

- Flexispot Height Adjustable Desk Frames

All height – adjustable desks purchased on or after October 5, 2016 include a 5-year warranty for the frame, and a 3-year warranty for the motor, controller, switch and other mechanisms.

- Flexispot Sit-Stand Desktop Workstations

All standing desks purchased on or after October 5, 2016 include a 5-year warranty for the frame and medium-fiber desktop, and a 3-year warranty for gas spring system and mechanisms.

- FlexiSpot Office Chairs

All desk chairs purchased on or after December 1, 2018 include a 3-year warranty for chair body, and other mechanisms.

What are your Remedies?

Flexispot will replace at no charge to the consumer the defective parts only or, at Flexispot's option, replace any product or part of the product that is defective because of improper workmanship and/or material, under normal installation, use, service and maintenance. If Flexispot is unable to provide a replacement and repair is not practical or cannot be completed in a timely fashion, Flexispot may elect to refund the purchase price in exchange for the return of the product. In the rare event that your Flexispot product is defective, we will provide you with a replacement item shipped at no cost to you within the continental United States. The shipping method for replacement products is FedEx Ground, but expedited shipping is available if you choose to pay the additional expense. In addition, you will need to pay the shipping costs if any products need to be shipped to you at an address outside the continental United States.

REPAIR OR REPLACEMENT (OR, IN LIMITED CIRCUMSTANCES, REFUND OF THE PURCHASE PRICE) AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. FLEXISPOT NEITHER ASSUMES NOR AUTHORIZES ANY PERSON TO CREATE FOR IT ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH THIS PRODUCT.

What is Not Covered?

Our limited warranty does not cover any problem that is caused by:

1. Conditions, malfunctions or damage not resulting from defects in material or workmanship.
2. Conditions, malfunctions or damage resulting from normal wear and tear, improper installation, improper maintenance, misuse, abuse, negligence, accident or alteration.
3. Accessories, connected materials and products, or related products not manufactured by Flexispot.
4. Conditions, malfunctions or damage resulting from failure to follow the instructions and guidelines relating to the product's intended use.

Our limited warranty is void if a product is returned with removed, damaged or tampered labels or any alterations (including removal of any component or external cover).

How to File a Claim?

In order to receive the benefit of our limited warranty, you need to process your claim in compliance with the terms of this limited warranty and follow proper return procedure. To request warranty service, please contact customer service via email at contact@flexispot.com or toll free at 855-421-2808. You will need to provide the sales receipt or other evidence of the date and place of purchase for your Flexispot product.

Implied Warranties and Limitation of Damages

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ALL IMPLIED WARRANTIES (INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY, AND FLEXISPOT SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS OR REVENUE, RESULTING FROM ANY BREACH OF EXPRESS OR IMPLIED WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, EVEN IF FLEXISPOT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some jurisdictions do not allow limitations on the duration of an implied warranty or the exclusion or limitation of special, indirect, incidental or consequential damages, so the above limitations or exclusions may not apply to you.

Governing Law

This Warranty shall be governed by the laws of the State of California, USA, without giving effect to any conflict of laws principles that may provide the application of the law of another jurisdiction.

How State Law Applies

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.


UNITED STATES

sales@flexispot.com
(855)421-2808
Monday-Friday
9:00-17:00(PST)

JAPAN

contact@flexispot.jp
+813-4589-4795
Monday-Friday
10:00-19:00(TYO)

FLEXISPOT



Item No. OC3B

Installation Guide

Office Chair 


オフィスチェア 

Office Chair


English: Pages 01 ~ 04

日本語: ページ05 ~ 08


PARTS




Mechanism



Backrest




Seat Cushion




2D PU Armrest




Nylon Base




Gas Lift




Screw M6X30mm




Screw M8X40mm




Screw M6X20mm




Gasket




Nylon Wheel




L Shape Wrench




Headrest



Gasket




Clothes Hanger



Screw M5X35mm


Step 1: Installing Backrest

Connect Mechanism (A) to the Backrest (B) using three screws (H).




Step 2: Installing Armrest to Seat Cushion

Connect 2D PU Armrest (D) to the Seat cushion (C) using 6 pcs screws (G).




Step 3: Attaching Backrest to Seat Cushion


Connect the Mechanism (A) to the seat cushion (C) using four screws (I).



Step 4: Installing Gas Lift and Wheels to Nylon Base




Step 5: Installing the Chair Body on the Gas Lift F




Step 6: Installing Headrest and Clothes Hanger

Attaching the headrest (O) to the backrest (B), then attaching the gasket (P) and clothes hanger (Q) to it using 2 screw (R) as shown below.




組み立て部品




ステップ1：背もたれに座面ブラケットを取り付けます

六角レンチ（L）とボルト（H）で座面ブラケット（A）を背もたれ（B）に固定してください。




ステップ2：座面に肘あてを取り付けます

ワッシャー（J）とボルト（G）で肘あて（D）を座面（C）に固定してください。




ステップ3：座面に背もたれを取り付けます

六角レンチ（L）とボルト（I）で背もたれ（A）を座面（C）に固定してください。




ステップ5：ガスシリンダーに座面を差し込みます



ステップ4：レッグフレーム部品の組み立て

- 1.レッグフレーム(E)をひっくり返して、それぞれのキャスター(K)を取り付けます。
(手ではめ込む)
- 2.上からガスシリンダー(F)を差し込みます。



ステップ6：ヘッドレストとハンガーを取り付けます

図のように、ヘッドレスト（O）を背もたれ（B）に取り付けます。
ガスケット（P）とボルト（R）でハンガー(Q)を取り付けます。

